



T1C0 T2C1 P5_234

IRCE

IRCF

IRCG

IRCH

RS-485

RS-232

VIN F

SPI2

USB

BOOT

USB PWR

CAN

TERM

CAN

I/O

SERIAL

ANALOG IN

ETH

SD CARD

IRCA

IRCB

IRCC

IRCD

SPI1

POWER_A

POWER OUTPUTS

POWER_B

VPWR GND
VIN

0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
HAL A HAL B HAL C HAL D HAL E

VPWR GND
VIN